



## Passenger Backrest Installation Instructions

*\*Read ALL instructions BEFORE attempting to install this product*

*\*Failing to follow these instructions could result in serious injury or damage to motorcycle*

*\*Advanced Sport Touring is not responsible for any injury or damage to property resulting from the use of this product*

**Included with Passenger Backrest:** (1) Backrest Pad, (1) Steel Backrest Bracket, Mounting Bolts

**Tools you will need:** 4mm Allen Key

- 1) You should not use Loctite on the hardware included in this kit. This system is designed to be adjustable and Loctite will prevent this from being possible.
- 2) Washers are only to be used in the connections between the vinyl backrest pad and the steel bracket, not when attaching the steel bracket to the luggage rack.
- 3) Push bolts through the vinyl pad before inserting the steel bracket. Pull the bolts out just far enough to slide the steel backrest bracket into the backrest pad. The backrest pad has two mounting possibilities (high and low position). Tighten bolts.
- 4) Slide the steel bracket under the Advanced Sport Touring luggage rack. Position bracket so bolts can be passed through the luggage rack and be threaded into the bracket (multiple positions available). Tighten bolts.
- 5) Installation complete.

---

**Maintenance:** Powder coating is designed to be more durable than paint but it's not invincible. It will scratch, scuff and chip.

---