



## Ram Ball Accessory Mount Installation Instructions

*\*Read ALL instructions BEFORE attempting to install this product*

*\*Failing to follow these instructions could result in serious injury or damage to motorcycle*

*\*Advanced Sport Touring is not responsible for any injury or damage to property resulting from the use of this product*

**\*\*You MUST use the supplied Loctite on the threads of the adapter when installing on your motorcycle. Failure to do so could result in the adapter backing out and losing control of the motorcycle.**

**Included:** (1) A.S.T. Ram Ball Accessory Mount, (1) RAM supplied ball & post, (1) Loctite

**Tools you will need:** 5mm Allen Key, 9mm open-ended wrench

- 1) Using a lead pencil or (non-permanent) marking device, mark the location of the handlebar clamp as indicated in **(Fig. 1)**. Doing this will allow you to put the clamp exactly where it was before you loosened the clamp bolts.
- 2) Remove any of the bolts indicated in **(Fig. 2)**. You should only have (1) bolt removed at a time. Test fit the Ram Ball Accessory Mount.
- 3) Apply the supplied Loctite to the threads of the mount and screw it into position. Using a 9mm wrench, tighten the mount so that the clamp is secured into position and there is no movement in the handlebars or the dash cover depending on your application.
- 4) Refer to the chart for drying times. You must wait till Loctite is completely dry before using.

