

# ADVANCED SPORT TOURING

For this installation, you'll need a couple tools which are listed below. Some are a "Must Have" and some are just "Recommended" to make your install easier. "Must Have" is the minimum. If you use a "Recommended" item, you don't need the "Must Have" from that category. I've also included links to a "cheap tool" company where you can get any of these items without forking out a lot of money. They sell most items in sets. You'll be able to find 20% off coupons for them in just about any "mens" magazine. Shop wherever you want! I am in no way affiliated with them. These are merely suggestions to give you a visual of the tools.

## TOOLS:

1. 8mm Hex Socket - **(MUST HAVE)**  
[Hex Socket Set](#)
2. 6" or more of socket extension - **(MUST HAVE ONE OF THE FOLLOWING)**  
[3/8 drive extension set](#)  
or  
[1/2 drive extension set](#)
3. Large Ratchet OR Breaker Bar  
Ratchet: **(MUST HAVE ONE OF THE FOLLOWING)**  
[3/8" Ratchet](#)  
or  
[1/2" Ratchet](#)  
  
Breaker Bar **(RECOMMENDED)**  
[3/8 breaker bar](#)  
or  
[1/2 breaker bar](#)
4. 4 & 5mm Hex Key or Hex Socket - **(MUST HAVE)**  
[Hex key set](#)
5. 10mm Open-Ended Wrench - **(MUST HAVE)**  
[Metric wrench set](#)