Single Ryker Helmet Lock Installation Instructions

**Read ALL instructions BEFORE attempting to install this product. *Failing to follow these instructions could result in serious injury or damage to motorcycle*

**Advanced Sport Touring is not responsible for any injury or damage to property resulting from the use of this product*

Included: (1) Helmet Locks with attached bracket, (1) 20mm bolts, (1) M8 Lock Nut, (2) Washers

Tools you will need: 6mm Hex Key, 13mm open-ended wrench or rachet/socket

1. Place washer on bolt.
2. Put bolt/washer through slot in bracket
3. Put the bolt/washer that's through the slot into either of the indicated holes on front side of hole. **Fig. 1**
4. Put washer onto other side of bolt and then the lock nut.
5. Recommended position of bracket is shown in **Fig.1** but you can position bracket how you like it.
6. Tighten nut with 6mm Hex Key and 13mm wrench.